



8 Gauge

**Wafer Head** 

**Button** 



Page 1 of 2

# **Metal SDS Button Wafer Phillips Head**

### Self Drilling Screw (SDS) #08-18

### **Applications**

- Backpans
- Foil Sarking
- · Fascia Brackets
- · Conduit Clips

Material 1022 C1022 Hardened

**Finish** 



Pullout Values							
Plate (Purlin)	Metal Plate Thickness	¹Mean Load	<sup>2</sup> Characteristic Load	³Working Load			
	(mm)	(N)	(N)	(N)			
G2	G2 0.7		800	300			
G2	1.1	1550	1400	550			
G550	G550 1.5		3150	1250			
G450	G450 2.0		4150	1650			
G450	2.5	6400	5450	2200			

#### **Drill Point Test Metal Plate Plate Drill Speed** Load **Drill Time Drill Time** (Purlin) **Thickness** (Max. (Max. (mm) (RPM) individual) (kg) average)

Mechanical Properties						
Torsional Strength	¹Mean Tensile Strength	<sup>1</sup> Mean Shear Strength	<sup>2</sup> Characteristic Tensile Strength	<sup>2</sup> Characteristic Shear Strength		
(Nm)	(N)	(N)	(N)	(N)		
4.7	8050	4850	6750	4050		

Note: 1000N = 1kN

1.5

G450

<sup>1</sup>Mean Load/Strength is the average ultimate strength of samples tested.

18

2200

All values are obtained under laboratory conditions using DRiLLX product. Safety factors should be considered for design purposes. Actual pullout loads may differ slightly depending on certain properties of the base material.

Disclaimer: While every reasonable effort has been made to ensure that this document is correct at the time of printing, Hobson Engineering®, its agencies and employees, disclaim any and all liability to any person in respect of anything or the consequences of anything done or omitted to be done in reliance upon the whole or any part of this document.

3





<sup>&</sup>lt;sup>2</sup>Characteristic Load/Strength: 95% of these screws are expected to have a strength greater than the loads shown.

<sup>&</sup>lt;sup>3</sup>Working Load is the governing minimum allowable load obtained by comparing relevant concrete and steel working loads. Factor of Safety (FOS=2.5 for steel, FOS=2.5 for timber and FOS=3.0 for concrete) are already included.

# PRODUCT DATA







## **Metal SDS Button Wafer Phillips Head**

Page 2 of 2


Part	QFind	Gauge	TPI	Length	Thread Length	Drill Point Length	Head Height	Head ø	Drive Size	Pack Qty
				L (mm)	T (mm)	DP (mm)	H (mm)	D (mm)	PH	
T9PMYAP0818012	Q430		18	12	7	5	2.3	10	Phillips #2	1000
T9PMYAP0818016	Q432	8		16	11					
T9PMYAP0818020	Q434			20	15					
T9PMYAP0818025	Q436			25	20					
T9PMYAP0818032	Q438			32	27					







### Installation









# Recommended Phillips Size #2 Drive Bit:

Part	QFind	Length	
		(mm)	
TXDIPPHS20050	B316	50	
TXDIPPHS20075	BA27	75	
TXDIPPHS20100	B326	100	
TXDIPPHS20150	B331	150	

### **Installation Guide**

- **1.** Use a cordless screw driver set between 2,200-3,000 RPM. Fit the Phillips Drive Bit over the screw and place at the fastening position.
- **2.** Apply consistently firm pressure to the screw driver while the screw is drilling.
- 3. Care should be taken not to over-tighten the screw.

Disclaimer: While every reasonable effort has been made to ensure that this document is correct at the time of printing, Hobson Engineering®, its agencies and employees, disclaim any and all liability to any person in respect of anything or the consequences of anything done or omitted to be done in reliance upon the whole or any part of this document.

HOBSON

<sup>\*</sup>Installation with impact drivers not recommended.