# PRODUCT DATA





Page 1 of 2

# **Metal SDS Bugle Head**

#### Self Drilling Screw (SDS) #06-20

## **Applications**

- Plasterboard and rigid board to steel frame
- Ceilings
- · Light gauge steel frame up to 3mm thick
- · Internal use only


Material C1022 Hardened

**Finish** 



Pullout Values						
Plate (Purlin)	Metal Plate <sup>1</sup> Mean <sup>2</sup> Characteristic Load Load		³Working Load			
	(mm)	(N)	(N)	(N)		
G550	0.5	750	550	200		
G2	0.7	800	650	250		
G2	1.2	1300	1200	450		
G550	1.6	2500	2000	800		

# 6 Gauge Bugle Head



Drill Point Test						
Plate (Purlin)	Metal Plate Thickness	Load Drill Speed		Drill Time	Drill Time	
	(mm)	(kg)	(RPM)	(Max. individual) Seconds	(Max. average) Seconds	
G450	1.5	18	2200	4.5	3	

Mechanical Properties						
Torsional Strength	<sup>1</sup> Mean Tensile Strength	<sup>1</sup> Mean Shear Strength	<sup>2</sup> Characteristic Tensile Strength	<sup>2</sup> Characteristic Shear Strength		
(Nm)	(N)	(N)	(N)	(N)		
2.7	7400	4450	6400	3850		

Note: 1000N = 1kN

All values are obtained under laboratory conditions using DRiLLX product. Safety factors should be considered for design purposes. Actual pullout loads may differ slightly depending on certain properties of the base material.

Disclaimer: While every reasonable effort has been made to ensure that this document is correct at the time of printing, Hobson Engineering®, its agencies and employees, disclaim any and all liability to any person in respect of anything or the consequences of anything done or omitted to be done in reliance upon the whole or any part of this document.



<sup>&</sup>lt;sup>1</sup>Mean Load/Strength is the average ultimate strength of samples tested.

<sup>&</sup>lt;sup>2</sup>Characteristic Load/Strength: 95% of these screws are expected to have a strength greater than the loads shown.

<sup>&</sup>lt;sup>3</sup>Working Load is the governing minimum allowable load obtained by comparing relevant concrete and steel working loads. Factor of Safety (FOS=2.5 for steel, FOS=2.5 for timber and FOS=3.0 for concrete) are already included.









## **Metal SDS Bugle Head**

Page 2 of 2

Part	QFind	Gauge	TPI	Length	Thread Length	Drill Point Length	Head Height	Head ø	Drive Size	Pack Qty
				L (mm)	T (mm)	DP (mm)	H (mm)	D (mm)	PH	
T9PMYBP0620025	Q440			25	15.5					
T9PMYBP0620030	Q442	6	20	30	20.5	4.5	6	8.4	Phillips #2	1000
T9PMYBP0620045	Q444			45	35.5					



### Installation



# Recommended Phillips Size #2 Drive Bit:

Part	QFind	Length	
		(mm)	
TXDIPPHS20050	B316	50	
TXDIPPHS20075	BA27	75	
TXDIPPHS20100	B326	100	
TXDIPPHS20150	B331	150	
TXDIPPHS20150	B331	150	

## **Installation Guide**

- **1.** Use a cordless screw driver set between 2,200-3,000 RPM. Fit the Phillips Drive Bit into the screw and place at the fastening position.
- **2.** Apply consistently firm pressure to the screw driver while the screw is drilling.
- 3. Care should be taken not to over-tighten the screw.

Disclaimer: While every reasonable effort has been made to ensure that this document is correct at the time of printing, Hobson Engineering®, its agencies and employees, disclaim any and all liability to any person in respect of anything or the consequences of anything done or omitted to be done in reliance upon the whole or any part of this document.



<sup>\*</sup>Installation with impact drivers not recommended.